INSTALLATION INSTRUCTIONS FOR SYMCOM'S MOTORSAVER® MODEL 460-SP

DANGER!

HAZARDOUS VOLTAGES MAY BE PRESENT DURING INSTALLATION. Electrical shock can cause death or serious injury. Installation should be done by qualified personnel following all national, state and local electrical codes.

BE SURE POWER IS DISCONNECTED PRIOR TO INSTALLATION! FOLLOW NATIONAL, STATE, AND LOCAL CODES! READ THESE INSTRUCTIONS ENTIRELY BEFORE INSTALLATION!

WARNING !

UNEXPECTED OUTPUT ACTUATION CAN OCCUR. Use hard-wired safety interlocks where personnel and/or equipment hazards exist. Failure to follow this instruction can result in death, injury or equipment damage.

The Model 460-SP MotorSaver[®] is a voltage monitor designed to protect single-phase motors regardless of size. The MotorSaver[®] is used on 190-240 (95-120) VAC, 50 to 60 Hz motors to protect from damage caused by low voltage and high voltage.

CONNECTIONS

4

- Mount the MotorSaver[®] in a convenient location in or near the motor control panel. If the location is wet or dusty, the MotorSaver[®] should be mounted in a NEMA 4 or 12 enclosure. The MotorSaver[®] can be mounted to a back panel using two #6 or #8 x 5/8 screws or can be snapped onto a DIN rail.
- 2. Connect L1 and L2 on the MotorSaver's terminal strip to the LINE SIDE of the motor starter (See Figure 1).
- 3. Connect the output relay to the circuitry to be controlled. For motor control, connect the normally open contact in series with the magnetic coil of the motor starter (See Figure 1). For alarm operation, connect the normally closed contact in series with the control circuit (See Figure 2).

-460-SP-B

www.SymCom.com

222 Disk Drive, Rapid City, SD 57701 (800) 843-8848 www.symcom.com







FIGURE 2: ALARM WIRING DIAGRAM

SETTINGS

- 1. Line voltage adjustment: Rotate the "VOLTAGE ADJ. (VAC)" to the nominal line voltage feeding the motor to be protected.
- 2. Restart delay adjustment: Rotate the "RESTART (SEC)" adjustment to the desired position. The restart delay is the time between the MotorSaver® seeing acceptable voltage and the MotorSaver® closing its output contacts. For compressor applications, the restart delay should be set for the approximate time it takes for the head pressure to bleed off of the compressor. For other applications, the restart delay is typically set between 2 and 10 seconds.



POWER-UP

Turn on the power to the motor. The MotorSaver's green RUN light will blink during the RESTART delay. After the RESTART delay, the MotorSaver[®] will energize its output contacts and the green RUN light will illuminate. If the contacts do not energize and the RUN light does not illuminate, see the TROUBLESHOOTING section.

DIAGNOSTIC INDICATOR LIGHTS		
RUN	GREEN	
RESTART DELAY	ாராரா GREEN	
HIGH / LOW VOLTAGE	RED	

CONGRATULATIONS!! YOU HAVE JUST INSTALLED THE FINEST MOTOR PROTECTION AVAILABLE!!

TROUBLESHOOTING

SYMPTOM	LIGHT PATTERN	SOLUTION
No lights are on. The unit seems completely dead.	N / A	Measure the voltage. If the voltage is below 75 VAC, the MotorSaver [®] does not have enough power to operate its internal elec- tronics. If the voltage is correct, call SymCom at 1-800-843-8848 or 1-605-348-5580.
Red light is on steady.	RED	The voltage is out of tolerance. Measure the input voltage. If the voltage is 7% above or below the nominal voltage as selected by the LINE VOLTAGE ADJUST, the MotorSaver [®] is functioning properly. If the voltage is within ±7% of the selected line voltage, call SymCom at 1-800-843-8848 or 1-605-348-5580.
Green light blinks and motor is not running.	காகக GREEN	The MotorSaver [®] is in restart delay.
Green light is on steady, but motor does not start.	GREEN	The MotorSaver [®] is in run mode. Ensure other control devices are allowing the motor to start. Check control circuit for loose wires or malfunctioning switches.

SPECIFICATIONS

1 - Phase Line Voltage	190 - 240 (95-120) VAC
Frequency	50* - 60 Hz
High Voltage (% of setpoint)	
Trip	110% ±1%
Reset	107% ±1%
Low Voltage (% of setpoint)	
Trip	90% ±1%
Reset	93% ±1%
Trip Delay Time	•
Low Voltage	4 Seconds Fixed
High Voltage	4 Seconds Fixed
Restart Delay Time	
After a complete power loss	1-500 Seconds Adjustable
Output Contact Rating - SPDT	
Pilot Duty	480 VA @ 240 VAC
General Purpose	10 A @ 240 VAC
Power Consumption	6 Watts (maximum)
Weight	14 oz
Enclosure	Polycarbonate
Terminal	-
Torque	6 Inch-Pounds
Wire AWG	12 - 20 AWG
Safety Marks	
UL	UL508 (File # E68520)
CE	IEC 60947-6-2
Standards Passed	
Electrostatic Discharge (ESD)	IEC 1000-4-2, Level 3, 6 kv contact, 8 kv air
Radio Frequency Immunity, Radiated	159 MHz, 10 V/m
Fast Transient Burst	IEC 1000-4-4, Level 3, 3.5 kv input power and controls

*NOTE: 50 Hz will increase all delay timers by 20%

Surge		
IEC	IEC 1000-4-5, Level 3, 4kv line-to-line; Level 4, 4kv line-to-ground	
ANSI / IEEE	C62.41 Surge and Ring Wave Compliance to a level of 6kv line-to-line	
Hi-potential Test	Meets UL508 (2 x rated V +1000V for 1 minute)	
Environmental		
Temperature Range	Ambient Operating: -20° - 70° C (-4° - 158°F) Ambient Storage: -40° - 80° C (-40° - 176°F)	
Class of Protection	IP20, NEMA 1 (Finger Safe)	
Relative Humidity	10-95%, non-condensing per IEC 68-2-3	

DIMENSIONS



SymCom warrants its microcontroller based products against defects in material or workmanship for a period of five (5) years* from the date of manufacture. All other products manufactured by SymCom shall be warranted against defects in material and workmanship for a period of two (2) years from the date of manufacture. For complete information on warranty, liability, terms, and conditions, please refer to the SymCom Terms and Conditions of Sale document.

Visit our website at www.symcominc.com for our complete catalog and new product listings!



222 Disk Drive, Rapid City, SD 57701 (800) 843-8848 www.symcom.com