
## **Technical Data Sheet**

# Rosenberger

# Cable assembly

RPC-1.00 Jack - UT-047-LL - RPC-1.85 Jack

L70-316-XXX



All dimensions are in mm; tolerances: ± 3mm for A ≤ 300 mm; ± 1% for A > 300 mm

#### **Available variants**

Туре	max. Insertion loss	Markin	g	Weight (g) / pce
L70-316-XXX	$\leq 0.0017 * \sqrt{f[GHz]} \frac{dB}{mm}$	ROSENBERGER L70-316-XXX	YYYY-WW sssss	$0.0059 \frac{g}{mm} * A[mm] + 4.60 g$

XXX – length in mm = A Maximum possible length = 6000mm WW – week YYYY – year sssss – serial no.

Note: Weight:

First constant = Cable weight per mm; Second Constant = Connector left and Connector right weight per pce

#### Assembly parts

Connector left RPC-1.00 Jack
Connector right RPC-1.85 Jack
Cable UT-047-LL
Armour none

#### **Electrical data**

Impedance 50  $\Omega$ 

Frequency DC to 70 GHz

Return loss<sup>1</sup>  $\geq$  17 dB, DC to 50 GHz  $\geq$  14 dB, 50 to 70 GHz Insertion loss<sup>1</sup> see table available variants

Individual testing and documentation:

Measurement plot with all 4 S – Parameters (S11; S22; S21; S12) is included with the cable assembly and on the backside the care and handling instruction is printed.

#### Mechanical data

Minimum bend radius:

Single 20.0 mm

### **Environmental data**

Temperature range - 40 °C to +85 °C compliant

While the information has been carefully compiled to the best of our knowledge, nothing is intended as representation or warranty on our part and no statement herein shall be construed as recommendation to infringe existing patents. In the effort to improve our products, we reserve the right to make changes judged to be necessary.

			Rev.	Engineering change number	Name	Date
Marcel Panicke 21.10	9 Ronny Mark	11.12.19	a00	19-s271	Marcel Panicke	11.12.19

Rosenberger Hochfrequenztechnik GmbH & Co. KG P.O.Box 1260 D-84526 Tittmoning Germany www.rosenberger.de

Tel. : +49 8684 18-0 Email : <u>info@rosenberger.de</u> Page

<sup>\*)</sup> If length "A" ≤ 90 mm marking is mount centric ± 5mm

<sup>&</sup>lt;sup>1</sup> Return Loss and Insertion Loss includes the measurement adaptor