OMRON

Switch Mode Power Supply S8VK-G (15/30/60/120/240/480-W Models)

Reliable and Easy Operation-Worldwide Power Supply Resistant in tough environments Easy and fast installation The most compact class on the market

- Universal input for worldwide applications: 100 to 240 VAC (85 to 264 VAC)
- DC input can be available: 90 to 350 VDC
- Possible for 2-phase input usage.
- Wide operation temperature range: -40 to 70 °C
- Power Boost function at 120%
- Safety standards: UL508/60950-1, CSA C22.2 No. 107.1/60950-1 EN50178, EN60950-1. Lloyd's standards, EN60204-1 PELV Safety of Power Transformers: EN61558-2-16
- ANSI/ISA 12.12.01 (excluding 480-W models)
- CSA C22.2 No.213 (excluding 480-W models)
- 15-W,30-W, and 60-W models conform to UL Class 2 output Standards
- EMS: EN 61204-3 EMI: EN 61204-3 Class B
- Three years Warranty *1

*1.Refer to Period and Terms of Warranty on page 22.

A Refer to Safety Precautions for All Power Supplies and Safety Precautions on page 17.





Model Number Structure

Model Number Legend

Note: Not all combinations are possible. Refer to List of Models in Ordering Information, below.



1. Input voltage type

G: Single phase

2. Power Ratings
015: 15 W
030: 30 W
060: 60 W
120: 120 W
240: 240 W
480: 480 W

3. Output voltage 05: 5 V 12: 12 V 24: 24 V 48: 48 V 4. Option None: Standard model

400: Coationg

Ordering Information

Note: For details on normal stock models, contact your nearest OMRON representative.

Power ratings	Input voltage	Output Voltage	Output current	Boost Current	Model number
		5 V	3 A	3.6 A	S8VK-G01505
15 W		12 V	1.2 A	1.44 A	S8VK-G01512
		24 V	0.65 A	0.78 A	S8VK-G01524
		5 V	5 A	6 A	S8VK-G03005
30 W		12 V	2.5 A	3 A	S8VK-G03012
	Single phase	24 V	1.3 A	1.56 A	S8VK-G03024
20.14/	100 to 240 VAC	12 V	4.5 A	5.4 A	S8VK-G06012
60 W	90 to 350 VDC	24 V	2.5 A	3 A	S8VK-G06024
20 W		24 V	5 A	6 A	S8VK-G12024
10.14		24 V	10 A	12 A	S8VK-G24024
240 W		48 V	5 A	6 A	S8VK-G24048
100.14		24 V	20 A	24 A	S8VK-G48024
480 W		48 V	10 A	12 A	S8VK-G48048

Specifications

Ratings, Characteristics, and Functions

		Power rating		15 W			30 W					
ltem		Output voltage	5 V	12 V	24 V	5 V	12 V	24 V				
Efficiency		230 VAC input *6	77% typ.	77% typ.	80% typ.	79% typ.	82% typ.	86% typ.				
	Voltage range *1		Single-phase, 85	o 264 VAC, 90 to 3	350 VDC *10							
	Frequency *1		50/60 Hz (47 to 450 Hz)									
	Current	115 VAC input *6	0.32 A typ.	0.3 A typ.	0.31 A typ.	0.5 A typ.	0.57 A typ.	0.58 A typ.				
	Current	230 VAC input *6	0.2 A typ.	0.21 A typ.	0.2 A typ.	0.32 A typ.	0.37 A typ.	0.36 A typ.				
nput	Power factor	230 VAC input, 100% load	0.42 min.			0.43 min.	0.42 min.	0.43 min.				
	Laskana aumont	115 VAC input	0.14 mA typ.			0.13 mA typ.	4					
	Leakage current	230 VAC input	0.25 mA typ.			0.24 mA typ.						
	Inrush current *2 (for	115 VAC input	16 A typ			16 A typ						
	a cold start at 25°C)	230 VAC input	32 A typ.			32 A typ.						
	Rated output currer	nt	3 A	1.2 A	0.65 A	5 A	2.5 A	1.3 A				
	Boost current		3.6 A	1.44 A	0.78 A	6 A	3 A	1.56 A				
	Voltage adjustment	range *3	-10% to 15% (wit	n V.ADJ) (guarante	ed)	l.						
	Ripple & Noise	100 to 240 VAC input,	60 mVp-p max. at 20	50 mVp-p max.at 20	30 mVp-p max. at 20	30 mVp-p max. at 20	30 mVp-p max. at 20	30 mVp-p max. at 20				
	voltage *4	100% load *6	MHz of bandwidth	MHz of bandwidth	MHz of bandwidth	MHz of bandwidth	MHz of bandwidth	MHz of bandwidth				
	Input variation influ	ence *8	0.4% max.			0.4% max.						
Output	Load variation influ	ence *7	0.8% max.			0.8% max.						
	Temperature variation influence	115 to 230 VAC input	0.05%/°C max.			0.05%/°C max.						
	Ohand and Plant die	115 VAC input *6	530 ms typ.	520 ms typ.	580 ms typ.	550 ms typ.	550 ms typ.	600 ms typ.				
	Start up time *2	230 VAC input *6	330 ms typ.	400 ms typ.	400 ms typ.	430 ms typ.	490 ms typ.	480 ms typ.				
		115 VAC input *6	28 ms typ.	29 ms typ.	32 ms typ.	33 ms typ.	36 ms typ.	23 ms typ.				
	Hold time *2	230 VAC input *6	134 ms typ.	138 ms typ.	134 ms typ.	177 ms typ.	170 ms typ.	154 ms typ.				
	Overload protection	•	Yes, automatic reset Yes, automatic reset					,,				
	Overvoltage protec		Yes, 130% or higher of rated output voltage, power shut off (shut off the input voltage and turn on the input again)									
Additional	Series operation		Yes (For up to two Power Supplies, external diodes are required.)									
functions	Parallel operation		Yes (Refer to Safety Precautions) (For up to two Power Supplies)									
	Output indicator		Yes (LED: Green), lighting from 80% to 90% or more of rated voltage									
			3.0 kVAC for 1 min. (between all input terminals and output terminals), current cutoff 20 mA									
	Withstand voltage			、 I	ut terminals and PE	1 ,,						
Insulation	J			· ·								
	Insulation resistance	e	1.0 kVAC for 1 min. (between all output terminals and PE terminals), current cutoff 20 mA 100 MΩ min. (between all output terminals and all input terminals/PE terminals) at 500 VDC									
	Ambient operating	temperature *12	-40 to 70°C (Derating is required according to the temperature. Refer to Engineering Data) (with no condensation or icing)									
	Storage temperatur		-40 to 85°C (with no condensation or icing)									
Environment	Ambient operating		0% to 95% (Storage humidity: 0% to 95%)									
	Vibration resistance		10 to 55 Hz, 0.375 mm half amplitude for 2 h each in X, Y, and Z directions									
	Shock resistance	·	150 m/s ² , 3 times each in $\pm X$, $\pm Y$, and $\pm Z$ directions									
	MTBF		135,000 hrs min.									
Reliability			10 years min.									
	Life expectancy *9											
	Weight	Weight										
Construction	-											
Construction	Cooling fan	n	No	0529								
Construction	Cooling fan Degree of protectio		No IP20 by EN/IEC 6									
Construction	Cooling fan	missions	No IP20 by EN/IEC 6 Conforms to EN 6	1000-3-2	N 55011 Class R							
Construction	Cooling fan Degree of protectio	missions Conducted Emissions	No IP20 by EN/IEC 6 Conforms to EN 6 Conforms to EN 6	1000-3-2 1204-3 Class B, E								
Construction	Cooling fan Degree of protectio Harmonic current e EMI	missions	No IP20 by EN/IEC 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6	1000-3-2 1204-3 Class B, E 1204-3 Class B, E	N 55011 Class B							
Construction	Cooling fan Degree of protectio Harmonic current e	missions Conducted Emissions	No IP20 by EN/IEC 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 UL Listed: UL 508 UL UR: UL 60950	1000-3-2 1204-3 Class B, E 1204-3 Class B, E 1204-3 high severi (Listing, Class2 O -1 (Recognition)	N 55011 Class B ty levels utput: Per UL 1310	, ,						
	Cooling fan Degree of protectio Harmonic current e EMI	missions Conducted Emissions Radiated Emissions	No IP20 by EN/IEC 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 UL Listed: UL 508 UL UR: UL 60950 cUL: CSA C22.2 h EN/VDE: EN 5017	1000-3-2 1204-3 Class B, E 1204-3 Class B, E 1204-3 high severi (Listing, Class2 O -1 (Recognition) Jo.107.1 (Class2 C Jo.60950-1 '8, EN 60950-1	N 55011 Class B ty levels	, ,						
	Cooling fan Degree of protectio Harmonic current e EMI EMS	missions Conducted Emissions Radiated Emissions s	No IP20 by EN/IEC 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 UL Listed: UL 508 UL UR: UL 609500 cUL: CSA C22.2 N cUR:CSA C2	1000-3-2 1204-3 Class B, E 1204-3 Class B, E 1204-3 high severi (Listing, Class2 O -1 (Recognition) vo.107.1 (Class2 C 0.60950-1 8, EN 60950-1 1	N 55011 Class B ty levels utput: Per UL 1310	, ,						
Construction Standards	Cooling fan Degree of protectio Harmonic current e EMI EMS Approved Standard	missions Conducted Emissions Radiated Emissions s	No IP20 by EN/IEC 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 Conforms to EN 6 UL Listed: UL 508 UL UR: UL 60950 cUL: CSA C22.2 N cUR: CSA C22.2 N C22.2 N C22.2 N C22.	1000-3-2 1204-3 Class B, E 1204-3 Class B, E 1204-3 high severi (Listing, Class2 O -1 (Recognition) vo.107.1 (Class2 C 0.60950-1 8, EN 60950-1 1 1, EN 50178)	N 55011 Class B ty levels utput: Per UL 1310	, ,						

*1. Do not use an inverter output for the Power Supply. Inverters with an output frequency of 50/60 Hz are available, but the rise in the internal temperature of the Power Supply

*1. Do not use an inverter output for the Power Supply. Inverters with an output frequency of 50/60 Hz are available, but the rise in the internal temperature of the Power Supply may result in ignition or burning.
*2. For a cold start at 25°C. Refer to *Engineering Data* on page 9 to 11 for details.
*3. If the output voltage adjuster (V. ADJ) is turned, the voltage will increase by more than +15% of the voltage adjustment range. When adjusting the output voltage, confirm the actual output voltage from the Power Supply and be sure that the load is not damaged.
*4. A characteristic when the ambient operating temperature is between -25 to 70°C.
*5. Refer to *Overvoltage Protection* on page 10 for the time when input voltage shuts off and input turns on again.
*6. The value is when both rated output voltage and rated output current are satisfied.
*7. 100 to 240 VAC input, in the range of 0 A to the rated output voltage is gradually changed within the allowable input voltage range at the rated output voltage and rated output current.
*9. Refer to *Recommended Replacement Periods and Periodic Replacement for Preventive Maintenance* on page 22 for details.
*10. Safety Standards for a DC Input.
*10. For a DC input, safety is ensured by an external fuse.
Select an external fuse that meets the following conditions.
\$8VK-G0150_1_350 VDC min, 3 A
\$8VK-G030_1_350 VDC min, 4 A
*11.Clamp filter "EA2030' manufactured by SCHAFFNER Corporation. or equivalent should be installed in the cable connected to the input - output terminals of S8VK-G series.
*12. At -40 to -25°C, time will be required before the rated output voltage is output after the input voltage is input.
Also, the ripple noise value may exceed the value shown in the above table.

		Power rating		60 W	120 W			
Item		Output voltage	12 V	24 V	24 V			
Efficiency		230 VAC input *6	85% typ.	88% typ.	89% typ.			
	Voltage range *1		Single-phase, 85 to 264 VAC, 90	0 to 350 VDC *10				
	Frequency *1		50/60 Hz (47 to 450 Hz)		50/60 Hz (47 to 63 Hz)			
		115 VAC input *6	1.0 A typ.	1.1 A typ.	1.3 A typ.			
	Current	230 VAC input *6	0.6 A typ.	0.7 A typ.	0.7 A typ.			
Input	Power factor	230 VAC input, 100% load	0.46 min.	0.45 min.	0.94 min.			
mput		115 VAC input	0.16 mA typ.	0.10 1111	0.24 mA typ.			
	Leakage current	230 VAC input	0.30 mA typ.		0.38 mA typ.			
	Inrush current *2 (for a cold start at 25°C)	115 VAC input	16 A typ.		16 A typ.			
		230 VAC input	32 A typ.	0.5.4	32 A typ.			
	Rated output current	nt	4.5 A	2.5 A	5 A			
	Boost current		5.4 A	3 A	6 A			
	Voltage adjustment	range *3	-10% to 15% (with V. ADJ) (gua	,				
	Ripple & Noise	100 to 240 VAC input,	150 mVp-p max.	50 mVp-p max.	150 mVp-p max.			
	voltage *4	100% load *6	at 20 MHz of bandwidth	at 20 MHz of bandwidth	at 20 MHz of bandwidth			
	Input variation influ		0.4% max.		0.4% max.			
Output	Load variation influ	ence *7	0.8% max.		0.8% max.			
	Temperature variation influence	115 to 230 VAC input	0.05%/°C max.		0.05%/°C max.			
	0	115 VAC input *6	570 ms typ.	650 ms typ.	790 ms typ.			
	Start up time *2	230 VAC input *6	430 ms typ.	500 ms typ.	750 ms typ.			
		115 VAC input *6	26 ms typ.	25 ms typ.	42 ms typ.			
Hold til	Hold time *2	230 VAC input *6	139 ms typ.	129 ms typ.	42 ms typ.			
	Overload protection		Yes, automatic reset		Yes, automatic reset			
	Overvoltage protec		Yes, 130% or higher of rated output voltage, power shut off (shut off the input voltage and turn on the input again)					
Additional	Series operation		Yes (For up to two Power Supplies, external diodes are required.)					
functions	Parallel operation		Yes (Refer to Safety Precautions) (For up to two Power Supplies)					
			Yes (LED: Green), lighting from 80% to 90% or more of rated voltage					
	Output indicator				, ,			
			3.0 kVAC for 1 min. (between all input terminals and output terminals), current cutoff 20 mA					
Insulation	Withstand voltage		2.0 kVAC for 1 min. (between all input terminals and PE terminals), current cutoff 20 mA					
			1.0 kVAC for 1 min. (between all output terminals and PE terminals), current cutoff 20 mA					
	Insulation resistant		100 M Ω min. (between all output terminals and all input terminals/PE terminals) at 500 VDC					
	Ambient operating	temperature *12	-40 to 70°C (Derating is required according to the temperature. Refer to Engineering Data) (with no condensation or icing					
	Storage temperatur		–40 to 85°C (with no condensation)	8/				
Environment	Ambient operating		0% to 95% (Storage humidity: 0%	,				
	Vibration resistance	e	10 to 55 Hz, 0.375 mm half amplitu		rections			
	Shock resistance		150 m/s ² , 3 times each in ±X, ±Y, ±Z directions					
Reliability	MTBF		135,000 hrs min.					
	Life expectancy *9		10 years min.					
	Weight		260 g max.		620 g max.			
Construction	Cooling fan		No					
	Degree of protectio		IP20 by EN/IEC 60529					
	Harmonic current e	missions	Conforms to EN 61000-3-2					
	ЕМІ	Conducted Emissions	Conforms to EN 61204-3 Class B, EN 55011 Class B					
		Radiated Emissions	Conforms to EN 61204-3 Class B, EN 55011 Class B					
	EMS		Conforms to EN 61204-3 high seve	erity levels				
			UL Listed: UL 508 (Listing, For 60 ¹ UL UR: UL 60950-1 (Recognition) cUL: CSA C22.2 No.107.1 (For 60 cUR: CSA C22.2 No.60950-1		,			
Standards	Approved Standard		EN/VDE: EN 50178, EN 60950-1 ANSI/ISA 12.12.01					
Standards			EN/VDE: EN 50178, EN 60950-1					
Standards	Approved Standard		EN/VDE: EN 50178, EN 60950-1 ANSI/ISA 12.12.01					
Standards			EN/VDE: EN 50178, EN 60950-1 ANSI/ISA 12.12.01 PELV (EN 60204-1, EN 50178)					

*1. Do not use an inverter output for the Power Supply. Inverters with an output frequency of 50/60 Hz are available, but the rise in the internal temperature of the Power Supply

*1. Do not use an inverter output for the Power Supply. Inverters with an output frequency of 50/60 Hz are available, but the rise in the internal temperature of the Power Supply may result in ignition or burning.
*2. For a cold start at 25°C. Refer to *Engineering Data* on page 9 to 11 for details.
*3. If the output voltage adjuster (V. ADJ) is turned, the voltage will increase by more than +15% of the voltage adjustment range. When adjusting the output voltage, confirm the actual output voltage from the Power Supply and be sure that the load is not damaged.
*4. A characteristic when the ambient operating temperature is between -25 to 70°C.
*5. Refer to *Overvoltage Protection* on page 10 for the time when input voltage shuts off and input turns on again.
*6. The value is when both rated output voltage and rated output current are satisfied.
*7. 100 to 240 VAC input, in the range of 0 A to the rated output voltage is gradually changed within the allowable input voltage range at the rated output voltage and rated output current.
*9. Refer to *Recommended Replacement Periods and Periodic Replacement for Preventive Maintenance* on page 22 for details.
*10. Safety Standards for a DC Input.
The following safety standards apply to a DC input: UL 60950-1, cUR (CSA C22.2 No. 60950-1), EN 50178, EN 60950-1, and Lloyd's. For a DC input, safety is ensured by an external fuse.
Select an external fuse that meets the following conditions.
S8VK-G060□□: 350 VDC min, 6 A
S8VK-G12024: 350 VDC min, 6 A
S8VK-G12024: 350 VDC min, 5 A
*11.Clamp filter "FN2080-10-06" manufactured by SCHAFFNER Corporation. or equivalent should be installed in the cable connected to the input - output terminals of S8VK-G series.
*12.At -40 to -25°C, time will be required before the rated output voltage is output after the input voltage is input. Also, the ripple noise value may exceed the value shown in the a

		Power rating	24	0 W	48	0 W		
Item		Output voltage	24 V	48 V	24 V	48 V		
Efficiency		230 VAC input *6	92% typ.		93% typ.			
	Voltage range *1		Single-phase, 85 to 264	VAC, 90 to 350 VDC *10				
	Frequency *1		50/60 Hz (47 to 63 Hz)					
	Current	115 VAC input *6	2.4 A typ.		4.7 A typ.			
	Current	230 VAC input *6	1.3 A typ.		2.3 A typ.			
Input	Power factor	230 VAC input, 100% load	0.9 min.		0.97 min.			
	Leakage current	115 VAC input	0.23 mA typ.		0.3 mA typ.			
	Leakage current	230 VAC input	0.33 mA typ.		0.49 mA typ.			
	Inrush current *2 (for	115 VAC input	16 A typ.		16 A typ.			
	a cold start at 25°C)	230 VAC input	32 A typ.		32 A typ.			
	Rated output current	nt	10 A	5 A	20 A	10 A		
	Boost current		12 A	6 A	24 A	12 A		
	Voltage adjustment	range *3	-10% to 15% (with V.AD.					
	Ripple & Noise	100 to 240 VAC input,	180 mVp-p max.	350 mVp-p max.	230 mVp-p max.	470 mVp-p max.		
	voltage *4	100% load *6	at 20 MHz of bandwidth	at 20 MHz of bandwidth	at 20 MHz of bandwidth	at 20 MHz of bandwidth		
Output	Input variation influ		0.4% max.		0.4% max.			
	Load variation influ		0.8% max.		0.8% max.			
	remperature variation influence	115 to 230 VAC input	0.05%/°C max.	000 ma tun	0.05%/°C max.			
	Start up time *2	115 VAC input *6	250 ms typ.	290 ms typ.	380 ms typ.			
	-	230 VAC input *6	250 ms typ.	290 ms typ.	260 ms typ.			
	Hold time *2	115 VAC input *6	44 ms typ.	43 ms typ.	40 ms typ.			
		230 VAC input *6	44 ms typ.		50 ms typ.			
	Overload protection		Yes, automatic reset		Yes, automatic reset			
Additional	Overvoltage protect	tion *5	Yes, 130% or higher of rated output voltage, power shut off (shut off the input voltage and turn on the input again)					
functions	Series operation		Yes (For up to two Power Supplies, external diodes are required.) Yes (Refer to <i>Safety Precautions</i>) (For up to two Power Supplies)					
	Parallel operation			7 1				
	Output indicator		Yes (LED: Green), lighting from 80% to 90% or more of rated voltage 3.0 kVAC for 1 min. (between all input terminals and output terminals), current cutoff 20 mA					
			2.0 kVAC for 1 min. (between all input terminals and output terminals), current cutoff 20 mA					
Insulation	Withstand voltage			•	<i>1</i> .			
	Insulation resistance		1.0 kVAC for 1 min. (between all output terminals and PE terminals), current cutoff 20 mA 100 MΩ min. (between all output terminals and all input terminals/PE terminals) at 500 VDC					
			-40 to 70 °C (Derating is required according to the temperature. Refer to <i>Engineering Data</i>) (with no condensation or icing)					
	Ambient operating Storage temperatur		-40 to 85°C (with no con	• •	nelel lo Engliteeting Dala) (with	no condensation of iding)		
Environment	Ambient operating							
Environment	Vibration resistance	•		6 to 95% (Storage humidity: 0% to 95%) to 55 Hz, 0.375 mm half amplitude for 2 h each in X, Y, and Z directions				
	Shock resistance	5	10 to 55 Hz, 0.375 mm hair amplitude for 2 h each in X, Y, and Z directions 150 m/s ² , 3 times each in ±X, ±Y, ±Z directions					
	MTBF		135,000 hrs min.					
Reliability	Life expectancy *9		10 years min.					
	Weight		900 g max.		1,500 g max.			
Construction	Cooling fan		900 g max. 1,500 g max.					
construction	Degree of protectio	n	IP20 by EN/IEC 60529					
	Harmonic current e		Conforms to EN 61000-3	-2				
	-	Conducted Emissions		Class B, EN 55011 Class	B			
	EMI	Radiated Emissions		,				
	EMS	naulateu Ellissiolis	Conforms to EN 61204-3 Class B, EN 55011 Class B Conforms to EN 61204-3 high severity levels					
Standards	Approved Standard	s	UL Listed: UL 508 (Listin UL UR: UL 60950-1 (Rec cUL: CSA C22.2 No.107. cUR: CSA C22.2 No.609 EN/VDE: EN 50178, EN 0 ANSI/ISA 12.12.01	g) ognition) 1 50-1				
			PELV (EN 60204-1, EN 5	50178)				
	Conformed Standar	ds	EN 61558-2-16	-1				
	Marda - Otan danda		Lloyd's register *10 *11					
	Marine Standards							

\$1. Do not use an inverter output for the Power Supply. Inverters with an output frequency of 50/60 Hz are available, but the rise in the internal temperature of the Power Supply may result in ignition or burning.
\$2. For a cold start at 25°C. Refer to *Engineering Data* on page 9 to 11 for details.
\$3. If the output voltage adjuster (V. ADJ) is turned, the voltage will increase by more than +15% of the voltage adjustment range. When adjusting the output voltage, confirm the actual output voltage from the Power Supply and be sure that the load is not damaged.
\$44. A characteristic when the ambient operating temperature is between -25 to 70°C.
\$5. Refer to *Overvoltage Protection* on page 10 for the time when input voltage shuts off and input turns on again.
\$6. The value is when both rated output voltage and rated output current estisfied.
\$7. 100 to 240 VAC input, in the range of 0 A to the rated output current
\$8. Fefer to *Recommended Replacement Periods and Periodic Replacement for Preventive Maintenance* on page 22 for details.
\$10. Safety Standards for a DC Input
The following safety standards apply to a DC input: UL 60950-1, cUR (CSA C22.2 No. 60950-1), EN 50178, EN 60950-1, and Lloyd's. For a DC input; safety is ensured by an external fuse.
S8VK-G2400:: 350 VDC min, 12 A
\$11. Clamp filter "ZCAT2035-0930" manufactured by TDK Corporation. or equivalent should be installed in the cable connected to the input - output terminals of S8VK-G series.
\$12. Adv or 2-2°C, time will be required by 5CHAFFNER Corporation. or equivalent should be connected to the input erminals of S8VK-G series.
\$12. Adv or 2-2°C, time will be required before the rated output voltage is output voltage is input. Also, the ripple noise value may exceed the value shown in the above table.

Also, the ripple noise value may exceed the value shown in the above table.

Connections

Block Diagrams

S8VK-G015 (15 W)



S8VK-G030 (30 W)



S8VK-G060 (60 W)



S8VK-G12024 (120 W)



S8VK-G240 (240 W)



S8VK-G480 (480 W)



Construction and Nomenclature

Nomenclature

15-W Models

120-W Models

S8VK-G12024

S8VK-G015



30-W Models

S8VK-G030

240-W Models

S8VK-G240

3 A



480-W Models S8VK-G480

60-W Models

S8VK-G060

4 Ļ ĕ -5 --2





Name	Function
Input terminals (L), (N)	Connect the input lines to these terminals. *1
Protective Earth terminal (PE)	Connect the ground line to this terminal. *2
DC Output terminals (–V), (+V)	Connect the load lines to these terminals.
Output indicator (DC ON: Green)	Lights while a direct current (DC) output is ON.
Output voltage adjuster (V.ADJ)	Use to adjust the voltage.
	Input terminals (L), (N) Protective Earth terminal (PE) DC Output terminals (–V), (+V) Output indicator (DC ON: Green)

*1. The fuse is located on the (L) side. It is not user-replaceable. For a DC input, connect the positive voltage to the L terminal.
*2. This is the protective earth terminal specified in the safety standards. Always ground this terminal.

Engineering Data

Derating Curve

15, 30, 240 W (S8VK-G015 , S8VK-G030 , S8VK-G240)



Note: 1. At less than 90 VAC, the derating is 2.5%/V

- For a DC power input, reduce the load given in the above derating curve by multiplying the following coefficients. S8VK-G015
 : 1.0 S8VK-G030
 : 0.9
 - S8VK-G030
- 3. This is the guaranteed value for startup.
- A. Standard mounting
- B. Face-up mounting / Side mounting (15W only)

60 W (S8VK-G060



Note: 1. At less than 90 VAC, the derating is 2.5%/V

- 3. This is the guaranteed value for startup.
- A. Standard mounting
- B. Face-up mounting

120 W (S8VK-G12024)



Note: 1. At less than 90 VAC, the derating is 2.5%/V

- For a DC power input, reduce the load given in the above derating curve by multiplying the following coefficients. S8VK-G12024: 0.9
 - 3. This is the guaranteed value for startup.
 - A. Standard mounting
 - B. Face-up mounting



- Note: 1. At less than 90 VAC, the derating is 2.5%/V

 - 3. This is the guaranteed value for startup.

 - A. Standard mounting
 - B. Face-up mounting

Mounting

(A) Standard (Vertical) mounting





(B) Face-up mounting

(C) Side mounting only for 15 W



Side mounting is only for S8VK-G015

Use a mounting bracket (S82Y-VK15P, sold separately) when the product is mounted horizontally.

Heat dissipation will be adversely affected. When the product is mounted facing horizontally, always place the side with label facing upward.

Overload Protection

The load and the power supply are automatically protected from overcurrent damage by this function.

Overload protection is activated if the output current rises above 121% of the rated current.

When the output current returns within the rated range, overload protection is automatically cleared.



The values shown in the above diagrams are for reference only.

- Note: 1. Internal parts may occasionally deteriorate or be damaged if a short-circuited or overcurrent state continues during operation.
 - Internal parts may possibly deteriorate or be damaged if the Power Supply is used for applications with frequent inrush current or overloading at the load end. Do not use the Power Supply for such applications.

Overvoltage Protection

Consider the possibility of an overvoltage and design the system so that the load will not be subjected to an excessive voltage even if the feedback circuit in the Power Supply fails. If an excessive voltage that is approximately 130% of the rated voltage or more is output, the output voltage is shut OFF. Reset the input power by turning it OFF for at least three minutes and then turning it back ON again.



The values shown in the above diagram is for reference only.

Note: Do not turn ON the power again until the cause of the overvoltage has been removed.

Inrush Current, Startup Time, Output Hold Time



Note: Twice the input current or above will flow during the parallel operation or redundant system. Therefore, check the fusing characteristics of fuses and

operating characteristics of breakers making sure that the external fuses will not burn out and the circuit breakers will not be activated by the inrush current.

Two phases application for Single phase models For All Single phase Models, S8VK-G

Basically OMRON single phase power supply can be used on twophases of a 3–phase-system when some of conditions satisfy like below.

- The supplying voltage is below the maximum rated input. OMRON Power supply allows the input voltage equivalent or less than 240 VAC+10%. Please confirm the input voltage between two lines if the input
- voltage satisfies this condition before connecting.
 2. The external protector is needed on N input line to secure a safety. N line has no protection of a fuse internally. An appropriate fuse or circuit breaker should be connected on N

An appropriate fuse or circuit breaker should be connected o input line like the following.



Reference Value

	Value
Reliability (MTBF)	Single phase model 15 W: 600,000 hrs 30 W: 580,000 hrs 60 W: 590,000 hrs 120 W: 450,000 hrs 240 W: 360,000 hrs 480 W: 230,000 hrs
Definition	MTBF stands for Mean Time Between Failures, which is calculated according to the probability of accidental device failures, and indicates reliability of devices. Therefore, it does not necessarily represent a life of the product.
Life expectancy	10 yrs. Min.
Definition	The life expectancy indicates average operating hours under the ambient temperature of 40°C and a load rate of 50%. Normally this is determined by the life expectancy of the built-in aluminum electrolytic capacitor.

Dimensions

S8VK-G015 (15 W)



S8VK-G030 (30 W)



S8VK-G060 (60 W)





S8VK-G12024 (120 W)



S8VK-G240 (240 W)



S8VK-G480 (480 W)





DIN Rail (Order Separately)

Note: All units are in millimeters unless otherwise indicated.

Mounting Rail (Material: Aluminum) PFP-100N

PFP-50N



Mounting Rail (Material: Aluminum) PFP-100N2



End Plate PFP-M



Note: If there is a possibility that the Unit will be subject to vibration or shock, use a steel DIN Rail. Otherwise, metallic filings may result from aluminum abrasion.

Mounting Brackets

Name	Model
Front-mounting bracket (for 15, 30 and 60 W models)	S82Y-VS10F
Front-mounting bracket (for 120, 240 and 480 W models)	S82Y-VK10F
Side-mounting bracket (for 15 W models)	S82Y-VK15P
Side-mounting bracket (for 30 and 60 W models)	S82Y-VS10S
Side-mounting bracket (for 120 W models)	S82Y-VK10S
Side-mounting bracket (for 240 W models)	S82Y-VK20S

Note: Be sure to use the accessory screws.

Mounting screw tightening torque (recommended): 4.43 to 5.31 lb-in (0.5 to 0.6 N·m)





* You can mount the side of the Power Supply to a DIN Rail by removing the DIN Rail Back-mounting Bracket and then attaching a Side-mounting Bracket to the Power Supply.

Safety Precautions

Warning Indications

	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.
Precautions for Safe Use	Supplementary comments on what to do or avoid doing, to use the product safely.
Precautions for Correct Use	Supplementary comments on what to do or avoid doing, to prevent failure to operate, malfunction or undesirable effect on product performance.

Meaning of Product Safety Symbols

	Used to warn of the risk of electric shock under specific conditions.
	Used to warn of the risk of minor injury caused by high temperatures.
0	Used for general mandatory action precautions for which there is no specified symbol.
	Use to indicate prohibition when there is a risk of minor injury from electrical shock or other source if the product is disassembled.

Minor electric shock, fire, or Product failure may occasionally occur. Do not disassemble, modify, or repair the Product or touch the interior of the Product.



Minor burns may occasionally occur. Do not touch the Product while power is being supplied or immediately after power is turned OFF.



Fire may occasionally occur. Tighten terminal screws to the specified torque (0.5 to 0.6 $\text{N}{\cdot}\text{m}).$



4

Minor injury due to electric shock may occasionally occur. Do not touch the terminals while power is being supplied. Always close the terminal cover after wiring.

Minor electric shock, fire, or Product failure may occasionally occur. Do not allow any pieces of metal or conductors or any clippings or cuttings resulting from installation work to enter the Product.



Precautions for Safe Use

Wiring

- Connect the ground completely. A protective earthing terminal stipulated in safety standards is used. Electric shock or malfunction may occur if the ground is not connected completely.
- Minor fire may possibly occur. Ensure that input and output terminals are wired correctly.
- Do not apply more than 75-N force to the terminal block when tightening it.
- Be sure to remove the sheet covering the Product for machining before power-ON so that it does not interfere with heat dissipation.
- Use the following material for the wires to be connected to the S8VK-G to prevent smoking or ignition caused by abnormal loads.

Recommended Wire Type/Cross-sectional Area and Stripping Length

	IN	IPUT	0	UTPUT		PE	
Model	American Wire Gauge	Solid Wire /Stranded Wire	American Wire Gauge	Solid Wire /Stranded Wire	American Wire Gauge	Solid Wire /Stranded Wire	Wire Stripping Length
S8VK-G01505			AWG20 to 12	0.5 to 4 mm ² /0.5 to 2.5 mm ²			
S8VK-G01512	$\Delta W(=2/1 \text{ to } 1/2)$	0.25 to 4 mm ² /0.25 to 2.5 mm ²	AWG22 to 12	0.35 to 4 mm ² /0.35 to 2.5 mm ²			
S8VK-G01524	-		AWG24 to 12	0.25 to 4 mm ² /0.25 to 2.5 mm ²			
S8VK-G03005			AWG18 to 12	0.75 to 4 mm ² /0.75 to 2.5 mm ²	- AWG14 to 12	2.5 to 4 mm ² /	8 to 10 mm
S8VK-G03012	AWG24 to 12	0.25 to 4 mm ² /0.25 to 2.5 mm ²	AWG20 to 12	0.5 to 4 mm ² /0.5 to 2.5 mm ²	- AWG14 10 12 - -	2.5 to 4 mm ²	
S8VK-G03024	-		AWG22 to 12	0.35 to 4 mm ² /0.35 to 2.5 mm ²			
S8VK-G06012	- AWG22 to 12	0.35 to 4 mm ²	AWG18 to 12	0.75 to 4 mm ² /0.75 to 2.5 mm ²			
S8VK-G06024	- AWG22 10 12	/0.35 to 2.5 mm ²	AWG20 to 12	0.5 to 4 mm ² /0.5 to 2.5 mm ²			
S8VK-G12024	AWG22 to 10	0.35 to 6 mm ² /0.35 to 4 mm ²	AWG18 to 10	0.75 to 6 mm ² /0.75 to 4 mm ²			Ť
S8VK-G24024	- AWG20 to 10	0.5 to 6 mm ²	AWG14 to 10	2.5 to 6 mm ² /2.5 to 4 mm ²		2.5 to 6 mm ² / 2.5 to 4 mm ²	
S8VK-G24048	AWG201010	/0.5 to 4 mm ²	AWG18 to 10	0.75 to 6 mm ² /0.75 to 4 mm ²	AWG14 to 10		
S8VK-G48024	- AWG16 to 10	1.5 to 6 mm ²	AWG12 to 10	4 to 6 mm ² /4 mm ²			
S8VK-G48048	AWG101010	/1.5 to 4 mm ²	AWG14 to 10	2.5 to 6 mm ² /2.5 to 4 mm ²			

• The wire insertion hole, and applicable screwdriver of the terminal block are as follows.

Model	Wire Insertion Hole (Refer to the diagram on the right)		Applicable Screwdriver			
	W	L	No.	Driver Diameter	Length	
S8VK-G01505						
S8VK-G01512						
S8VK-G01524				3.5 mm max.		
S8VK-G03005	0.7		#1		4.5 mm min.	
S8VK-G03012	- 2.7					
S8VK-G03024		2.9				
S8VK-G06012						
S8VK-G06024						
S8VK-G12024						
S8VK-G24024						
S8VK-G24048	2.9		#2	4.9 mm max.	10 mm min.	
S8VK-G48024	1					
S8VK-G48048	1					

Installation Environment

- Do not use the Power Supply in locations subject to shocks or vibrations. In particular, install the Power Supply as far away as possible from contactors or other devices that are a vibration source. For usage onboard a ship, always attach an End Plate (PFP-M) to both sides of the Power Supply to hold the Power Supply in place.
- Install the Power Supply well away from any sources of strong, high-frequency noise and surge.

Operating Life

 The life of a Power Supply is determined by the life of the electrolytic capacitors used inside. Here, Arrhenius Law applies, i.e., the life will be cut in half for each rise of 10°C or the life will be doubled for each drop of 10°C. The life of the Power Supply can thus be increased by reducing its internal temperature.

Ambient Operating and Storage Environments

- Store the Power Supply at a temperature of -40 to 85°C and a humidity of 0% to 95%.
- Do not use the Power Supply in areas outside the derating curve otherwise, internal parts may occasionally deteriorate or be damaged.
- Use the Power Supply at a humidity of 0% to 95%.
- Do not use the Power Supply in locations subject to direct sunlight.
- Do not use the Power Supply in locations where liquids, foreign matter, or corrosive gases may enter the interior of Products.

Mounting

- Take adequate measures to ensure proper heat dissipation to increase the long-term reliability of the Product. Be sure to allow convection in the atmosphere around devices when mounting. Do not use in locations where the ambient temperature exceeds the range of the derating curve.
- When cutting out holes for mounting, make sure that cuttings do not enter the interior of the Products.



- *1. Convection of air*2. 20 mm min.
- Improper mounting will interfere with heat dissipation and may occasionally result in deterioration or damage of internal parts. Use the Product within the derating curve for the mounting direction that is used.
- Use a mounting bracket when the Product is mounted facing horizontally.
- Heat dissipation will be adversely affected. When the Product is mounted facing horizontally, always place the side with the label facing upward.

DIN Rail Mounting

To mount the Block on a DIN Rail, hook portion (A) of the Block onto the rail and press the Block in direction (B).



To dismount the Block, pull down portion (C) with a flat-blade screwdriver and pull out the Block.



Power Boost Function

For All Models

Power Boost is a function that can output the temporary repeated boost current larger than the rated current.

However, it should meet the following four Boost current conditions.

- Time that the boost current flows: t1
 The maximum value of the boost current: lp
- **3.** The average output current: lave
- 4. The time ratio of the boost current flow: Duty

Note: Boost current conditions

Duty=
$$\frac{t1}{t1 + t2} \times 100 \, [\%] \le 30\%$$



- Do not allow the boost current to continue for more than 10 seconds. Also, do not let the duty cycle exceed the boost current conditions. These conditions may damage the Power supply.
- Ensure that the average current of one cycle of the boost current does not exceed the rated output current. This may damage the Power Supply.
- Lessen the load of the boost load current by adjusting the ambient temperature and the mounting direction.

Overcurrent Protection

- Internal parts may possibly deteriorate or be damaged if a short-circuited or overcurrent state continues during operation.
- Internal parts may possibly deteriorate or be damaged if the Power Supply is used for applications with frequent inrush current or overloading at the load end. Do not use the Power Supply for such applications.
- The DC ON indicator (green) flashes if the overload protection function operates.

Charging a Battery

If you connect a battery as the load, install overcurrent control and overvoltage protection circuits.

Output Voltage Adjuster (V.ADJ)

- The output voltage adjuster (V.ADJ) may possibly be damaged if it is turned with unnecessary force. Do not turn the adjuster with excessive force.
- After completing output voltage adjustment, be sure that the output capacity or output current does not exceed the rated output capacity or rated output current.

Series Operation

Two power supplies can be connected in series.



Note: 1. The diode is connected as shown in the figure. If the load is short-circuited, a reverse voltage will be generated inside the Power Supply. If this occurs the Power Supply may possibly deteriorate or be damaged. Always connect a diode as shown in the figure. Select a diode having the following ratings.

Туре	Schottky Barrier diode
Dielectric strength (VRRM)	Twice the rated output voltage or above
Forward current (IF)	Twice the rated output current or above

 Although Products having different specifications can be connected in series, the current flowing through the load must not exceed the smaller rated output current.

Making Positive/Negative Outputs

 The outputs are floating outputs (i.e., the primary circuits and secondary circuits are separated). You can therefore make positive and negative outputs by using two Power Supplies. You can make positive and negative outputs with any of the models.

If positive and negative outputs are used, connect Power Supplies of the same model as in the following figure. (Combinations with different output capacities or output voltages can be made. However, use the lower of the two maximum rated output currents as the current to the loads.)



 Depending on the model, internal circuits may be damaged due to startup failure when the power is turned ON if loads such as a servomotor or operational amplifier may operate in series. Therefore, connect bypass diodes (D1, D2) as shown in the following figure.



• Use the following information as a guide to the diode type, dielectric strength, and current.

Туре	Schottky Barrier diode
Dielectric strength (VRRM)	Twice the rated output voltage or above
Forward current (IF)	Twice the rated output current or above

Parallel Operation

Parallel operation is used when the output current from one Power Supply is insufficient for the load. Power Supplies are connected in parallel to increase the output current.

The parallel operation of S8VK-G is possible to increase the output power.

However please consider the following notes when the parallel operation must be done.

- 1. The range of ambient temperature for Parallel operation is –25 to 40° C.
- 2. Up to two of the same model can be connected in parallel.
- Adjust the output voltage difference of each Power Supply to 50 mV or less, using the output voltage adjuster (V. ADJ).
- 4. There is no current balancing function for S8VK-G. A high output voltage unit may work at overcurrent state and in this situation, a life of a Power Supply will be extremely short. After adjusting the output voltage, confirm the output current of the two Power Supplies balances.
- **5.** Using the parallel operation will not satisfy UL1310 Class2 output.
- 6. For Parallel Operation, to balance the current of the each unit, the length and thickness of each wire connected to the load and each
- unit must be same as much as possible.
 7. If you use the 15-W to 240-W S8VK-G in parallel operation, the output voltage may drop by several volts if the load changes rapidly (e.g., if the load starts or is disconnected). If operation becomes unstable, use the S8VK-R as shown in the diagram.



8. If you use the 480-W S8VK-G in parallel operation, the output voltage may drop by several volts if the load changes rapidly (e.g., if the load starts or is disconnected). If operation becomes unstable, connect a diode as shown in the diagram.



• Use the following information as a guide to the diode type, dielectric strength, and current.

Туре	Schottky Barrier diode
Dielectric strength (VRRM)	Twice the rated output voltage or above
Forward current (IF)	Twice the rated output current or above

Backup Operation

Backup operation is possible if you use two Power Supplies of the same model.

 $\ensuremath{\mathsf{Even}}$ if one Power Supplies fails, operation can be continued with the other Power Supply.

Make sure that the maximum load does not exceed the capacity of one Power Supply.

For backup operation, connect the S8VK-R as shown in the figure.



Refer to the S8VK-R datasheet (Catalog No.: T059) for S8VK-R specifications and the model number for each capacity.

In Case There Is No Output Voltage

The possible cause for no output voltage may be that the overcurrent or overvoltage protection has operated. The internal protection may operate if a large amount of surge voltage such as a lightening surge occurs while turning ON the power supply.

In case there is no output voltage, please check the following points before contacting us:

- Checking overload protected status: Check whether the load is in overload status or is short-circuited. Remove wires to load when checking.
- Checking overvoltage or internal protection: Turn the power supply OFF once, and leave it OFF for at least

3 minutes. Then turn it ON again to see if this clears the condition.

Audible Noise at Power ON

(120-W, 240-W, and 480-W Models)

A harmonic current suppression circuit is built into the Power Supply. This circuit can create noise when the input is turned ON, but it will last only until the internal circuits stabilize and does not indicate any problem in the Product.

Period and Terms of Warranty

Warranty Period

The product warranty is valid for a period of three years from the date of shipment from the factory.

Terms of Warranty

- The warranty is valid only for the following operating conditions.
- 1. Average ambient operating temperature of the product: $40^{\circ}C$ max.
- 2. Average load rate: 80% max.

3. Mounting method: Standard mounting

* The maximum ratings must be within the derating curve.

If the product fails for reasons attributable to OMRON within the above warranty period, OMRON will repair or replace the faulty part of the product at the place of purchase or the place where the product delivered without charge.

This warranty does not cover the following types of failures.

(1) Failures that result from handling or operation of the product under conditions or in environments that are not given in this document and not given in any other specifications exchanged between OMRON and the customer

- (2) Failures that originate in causes other than the delivered product itself
- (3) Failures caused by disassembly, modification, or repair of the product by anyone other than OMRON
- (4) Failures caused by applications or uses for which the product was not originally intended
- (5) Failures caused by factors that could not be anticipated with the scientific or technical knowledge available when the product was shipped (6) Failures caused by other causes for which OMRON is not responsible, such as natural disasters and other acts of God
- This warranty is limited to the individual product that was delivered and does not cover any secondary, subsequent, or related damages.

Recommended Replacement Periods and Periodic Replacement for Preventive Maintenance

The recommended replacement period for preventive maintenance is greatly influenced by the application environment of the product. As a guideline, the recommended replacement period is 7 to 10 years.* To prevent failures or accidents that can be caused by using a product beyond its service live, we recommend that you replace the product as early as possible within the recommended replacement period. However, bear in mind that the recommended replacement period is for reference only and does not guarantee the life of the product.

Many electronic components are used in the product and the product depends on the correct operation of these components to achieve the original product functions and performance.

However, the influence of the ambient temperature on aluminum electrolytic capacitors is large, and the service life is reduced by half for each 10°C rise in temperature (Arrhenius law).

When the capacity reduction life of the electrolytic capacitor is reached, the product failures or accidents may occur.

We therefore recommend that you replace the product periodically to minimize product failures or accidents in advance.

* The recommended replacement period applies under the following conditions: rated input voltage, load rate of 50% max., ambient temperature of 40°C max., and the standard mounting method.

This product model is designed with a service life of 10 years minimum under the above conditions.

Noise Filter S8V-NF (Single-phase 250 V 3 A / 6 A Type)

DIN Rail Mounting Type Ideal for Control Panels Featuring a Slim Design that Saves Space Push-In Connections for Safe and Easy Wiring

- 150 kHz to 1 MHz high attenuation
- Operation possible at ambient temperatures from -40 to 85°C
- Complies with RoHS directives
- Certification for 3,000 m altitude (UL/EN 60939)
- Five years Warranty *1

***1.** Refer to "Period and Terms of Warranty" on page 31 for details.



A Refer to "Safety Precautions" on page 28.

Model Number Structure

Model Number Legend

Note: Not all combinations are possible. Refer to List of Model number in Ordering Information, below.

S8V-NF <u>S</u> 2 1 2 3

1. Input type S: Single-phase AC/DC 2. Rated voltage 2: 250 VAC/250 VDC **3. Rated current** 03: 3 A 06: 6 A

Ordering Information

Note: For details on normal stock models, contact your nearest OMRON representative.

Rated voltage	Rated current	Model number
250 VAC	3 A	S8V-NFS203
250 VDC	6 A	S8V-NFS206

Ratings and Characteristics

Item	Rated current	3 A	6 A	
Rated voltage		Single-phase 250 VAC 50/60 Hz *1 , 250 VDC		
	Leakage current	1.0 mA max. (250 VAC/60 Hz)		
	DC resistance	110 mΩ max.		
I/O characteristics	Attenuation	25 dB min. (Common Mode: 0.1 to 10 MHz, Normal Mode: 0.2 to 30 MHz)		
characteristics	Withstand voltage	2.5 kVAC for 1 min. (between line and ground),	current cutoff 10 mA	
	Insulation resistance	100 MΩ min. (500 VDC, 1 min.)		
	Ambient operating temperature	40 to 85°C (Derating is required. Refer to <i>Engineering Data</i>) (with no condensation or icing)		
	Derating start temperature	+85°C	+60°C	
Environment	Storage temperature	-40 to 85°C (with no condensation or icing)		
Environment	Ambient operating humidity	95% (Storage humidity: 95% max.)		
	Vibration resistance	10 to 55 Hz, maximum 5 G, 0.42 mm half ampli	tude for 2 h each in X, Y, and Z directions	
	Shock resistance 150 m/s ² , 3 times each in ±X, ±		X, ±Y, ±Z directions	
Construction	Weight	140 g max.		
Construction	Degree of protection	IP20 by EN/IEC 60529		
Standards	Safety standards	UL 60939 (Recognition) OVC III (≤3000 m) Pol2 CSA C22.2 No.8 EN 60939 OVC III (≤3000 m) Pol2 ENEC *2 EAC (TR CU 004 / 2011)		

*1. If the input is connected to a UPS, do not connect a UPS with a square-wave output. Doing so will cause the internal temperature of the product to increase, possibly causing smoking or damage.

*2. ENEC is a certification that makes product distribution to EU member countries, EFTA (European Free Trade Association) member countries, and Eastern European countries possible.

Connections

Circuit Diagram



Construction and Nomenclature

Nomenclature

S8V-NFS203, S8V-NFS206

No.	Terminal name	Name	Function
1	L1		
2	L2	Line terminals	Connect the input lines to these terminals #1
3	N1	Line terminais	Connect the input lines to these terminals. *1
4	N2		
5	NC	No connection	Do not wire.
6	L'1		
7	L'2	Load terminals	Connect the output lines to these terminals.
8	N'1		*1
9	N'2		
10	PE	Protective Earth terminal (PE)	Connect the ground line to this terminal. *2

*1. Wiring is generally laid out so that the line terminal is connected to the input side and the load terminal is connected to the output side, though use in the opposite direction is also possible. Note that if the input and output are wired in reverse, the appropriate attenuation characteristics may

not be obtained. ***2.** This is the protective earth terminal specified in the safety standards. Always ground this terminal.

Engineering Data

Derating Curves S8V-NFS203



Note: If using at an altitude of 2000 m to 3000 m, multiply the above derating curve by 0.8 to reduce the load. (Does not apply for face-up mounting)

Attenuation Frequency Characteristics (Typical example) **S8V-NFS203 S8V-NFS206**



The above characteristics are data acquired by the following measurement circuits.

Common mode



Note: The noise filter attenuation characteristics are measured under a constant I/O impedance of 50 Ω. When used attached to actual equipment, the power line impedance varies depending on the wiring method. Therefore, attenuation characteristics may not match those listed in the catalog

Normal mode

S8V-NFS206



Note: If using at an altitude of 2000 m to 3000 m, multiply the above derating curve by 0.8 to reduce the load. (Does not apply for face-up mounting)



50 Ω

S8V-NF

Dimensions

S8V-NFS203 S8V-NFS206



Mounting Brackets

Name	Model number
Front-mounting bracket	S82Y-VS10F
Side-mounting bracket	S82Y-VS10S

Name	Model number	Dimensions	Appearance
Front-mounting bracket	S82Y-VS10F	$4.5 \text{ dia.}^{\pm 0.1}$ $4.5 \text{ dia.}^{\pm 0.1}$ $50 \text{ dia.}^{\pm 0.1}$ $7.3 \text{ dia.}^{\pm 0.1}$ $10 \text{ dia.}^{\pm 0.1}$ t = 1.0	
Side-mounting bracket	S82Y-VS10S	4.5 dia. $z_{0.1}$ 4.5 dia. $z_{0.1}$ 4.5 dia. $z_{0.1}$ 60 $z_{0.1}$ 60 $z_{0.1}$ t = 2.0	Left-side-noonntige Right-side-noonntige

DIN Rails (Order Separately)

(Unit: mm)

Mounting Rail (Material: Aluminum) PFP-100N PFP-50N



Mounting Rail (Material: Aluminum) PFP-100N2





7.3±0.15 -

Note: If there is a possibility that the Unit will be subject to vibration or shock, use a steel DIN Rail. Otherwise, metallic filings may result from aluminum abrasion.

S8V-NF

Safety Precautions

Warning Indications

	Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally, there may be significant property damage.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.
Precautions for Safe Use	Supplementary comments on what to do or avoid doing, to use the product safely.
Precautions for Correct Use	Supplementary comments on what to do or avoid doing, to prevent failure to operate, malfunction or undesirable effect on product performance.

Meaning of Product Safety Symbols

	Used to warn of the risk of electric shock under specific conditions.
	Used to warn of the risk of minor injury caused by high temperatures.
	Used to indicate prohibition when there is a risk of minor injury from electrical shock or other source if the product is disassembled.
0	Used for general mandatory action precautions for which there is no specified symbol.

/ WARNING

The electrical wire may come out and an electric shock may be caused. Insert the solid wire or ferrule straight into the terminal block until the end touches the terminal block.



Minor electric shock, fire, or product failure may occasionally occur. Do not disassemble, modify, or repair the product or touch the interior of the product.

Minor burns may occasionally occur. Do not touch the product while power is being supplied or immediately after power is turned OFF.



Minor injury due to electric shock may occasionally occur. Do not touch the terminals while power is being supplied.



Minor electric shock, fire, or product failure may occasionally occur. Do not allow any pieces of metal, conductors, or cuttings from installation work to enter the product.



Fire or product failure may occasionally occur. Do not use on the secondary side (output side) of inverters, etc.



Precautions for Safe Use

Installation Environment

- Do not use the product in locations subject to shocks or vibrations. In particular, install the product as far away as possible from contactors or other devices that are a vibration source.
- · Install the product well away from any sources of strong, highfrequency noise and surge.

Ambient Operating and Storage Environments

- Store the product at a temperature of -40 to 85°C and a humidity of 95% or less.
- · Do not use the product in areas outside the derating curve otherwise, internal parts may occasionally deteriorate or be damaged.
- · Use the product at a humidity of 95% max.
- Do not use the product in locations subject to direct sunlight.
- · Do not use locations where liquids, foreign matter, or corrosive gases may enter the interior of the product.

Mounting

- Take adequate measures to ensure proper heat dissipation to increase the long-term reliability of the product. Be sure to allow convection in the atmosphere around devices when mounting. Do not use in locations where the ambient temperature exceeds the range of the derating curve.
- · When cutting out holes for mounting, make sure that cuttings do not enter the interior of the product.



***1.** Convection of air *2. Vertical separation: 25 mm or more *1. Convection of air *2.20 mm min.

(A) Standard (Vertical) mounting





- Note: Horizontal separation
 - (A), (B): 15 mm or more : 0 mm or more and 15 mm or less. (C)



Wiring

- Connect the ground completely. A protective earthing terminal stipulated in safety standards is used. Electric shock or malfunction may occur if the ground is not connected completely.
- When you insert wires or insert a screwdriver into a release hole, do not press down on the terminal block with a force of 40 N or greater.
- · Do not wire anything to the release holes.
- Do not tilt or twist a flat-blade screwdriver while it is inserted into a release hole on the terminal block. The terminal block may be damaged.
- Insert a flat-blade screwdriver into the release holes at an angle. The terminal block may be damaged if you insert the screwdriver straight in.
- Do not allow the flat-blade screwdriver to fall out while it is inserted into a release hole.
- Do not bend a wire past its natural bending radius or pull on it with excessive force. This may cause a wire to be broken.
- Do not insert more than one wire into each terminal insertion hole.
- Do not pre-solder the ends of the wires. Doing so will inhibit proper connection.
- Be sure to remove the sheet covering the product for machining before power-ON so that it does not interfere with heat dissipation.
- If there is a possibility of vibration or shock, please use wires and stranded wires with ferrules.
- To prevent wiring materials from ignition or smoking, confirm wire ratings and use the wiring materials given in the following table.

Terminal	Model number	Recommende	ed wire gauge
rennnai	wodernumber	(mm²)	(AWG)
I/O terminals	S8V-NFS203	0.5 to 2.5	20 to 14
	S8V-NFS206	0.75 to 2.5	18 to 14
PE (protective earth) terminal	S8V-NFS203 S8V-NFS206	2 to 2.5	14

- Crossover wiring can be used for this product.
- However, do not allow the total steady-state current to terminals to exceed 10 A.
- The above table gives the recommended wires for one product.
- When using crossover wiring, select wiring materials suitable for the total current that will flow to terminals.

Stripping length

Recommended Wire	Stripping length (Ferrules not used)
0.34 to 1.5 mm ² /AWG20 to 16	8 mm
2 to 2.5 mm ² /AWG14	10 mm

Precautions for Correct Use

DIN Rail Mounting

To mount the Block on a DIN Rail, hook portion (A) of the Block onto the rail and press the Block in direction (B).



To dismount the Block, pull down portion (C) with a flat-blade screwdriver and pull out the Block.



Connecting Wires to the Push-In Plus Terminal Block Part Names of the Terminal Block



Connecting Wires with Ferrules and Solid Wires

Insert the solid wire or ferrule straight into the terminal block until the end touches the terminal block.



• If a wire is difficult to connect because it is too thin, use a flat-blade screwdriver in the same way as when connecting stranded wire.

Connecting Stranded Wires

- Use the following procedure to connect the wires to the terminal block.
- 1. Hold a flat-blade screwdriver at an angle and insert it into the release hole.

The angle should be between 10° and 15° . If the flat-blade screwdriver is inserted correctly, you will feel the spring in the release hole.

- 2. With the flat-blade screwdriver still inserted into the release hole, insert the wire into the terminal hole until it strikes the terminal block.
- **3.** Remove the flat-blade screwdriver from the release hole.



Checking Connections

- After the insertion, pull gently on the wire to make sure that it will not come off and the wire is securely fastened to the terminal block
- If you use a ferrule with a conductor length of 10 mm, part of the conductor may be visible after the ferrule is inserted into the terminal block, but the product insulation distance will still be satisfied.

Removing Wires from the Push-In Plus Terminal Block

Use the following procedure to remove wires from the terminal block. The same method is used to remove stranded wires, solid wires, and ferrules.

- 1. Hold a flat-blade screwdriver at an angle and insert it into the release hole.
- **2.** With the flat-blade screwdriver still inserted into the release hole, remove the wire from the terminal insertion hole.
- 3. Remove the flat-blade screwdriver from the release hole.





Recommended Ferrules and Crimping Tools Recommended Ferrules

Applicable wire		Ferrule Conductor	Stripping length (mm)	Recommended ferrules		
(mm²)	(AWG)	length (mm)	(Ferrules used)	Manufactured by Phoenix Contact	Manufactured by Weidmuller	Manufactured by Wago
0.50	20	8	10	AI 0,5-8	H0.5/14	FE-0.5-8N-WH
0.50		10	12	AI 0,5-10	H0.5/16	FE-0.5-10N-WH
0.75	18	8	10	AI 0,75-8	H0.75/14	FE-0.75-8N-GY
		10	12	AI 0,75-10	H0.75/16	FE-0.75-10N-GY
1/1.25	18/17	8	10	AI 1-8	H1.0/14	FE-1.0-8N-RD
		10	12	Al 1-10	H1.0/16	FE-1.0-10N-RD
1.25/1.5	17/16	8	10	Al 1,5-8	H1.5/14	FE-1.5-8N-BK
1.25/1.5		10	12	Al 1,5-10	H1.5/16	FE-1.5-10N-BK
2.5	14	10	12	AI 2,5-10	H2.5/16DS	FE-2.5-10N-BU
Recommended crimp tool				CRIMPFOX6 CRIMPFOX6T-F CRIMPFOX10S	PZ6 roto	Variocrimp4

Note: 1. Make sure that the outer diameter of the wire is smaller than the inner diameter of the insulating sleeve of the recommended ferrule.

2. Make sure that the ferrule processing dimensions conform to the following figure.



Recommended Flat-blade Screwdriver

Use a flat-blade screwdriver to connect and remove wires. Use the following flat-blade screwdriver.

The following table shows manufacturers and models as of 2015/Dec.



Model number	Manufacturer
ESD 0,40×2,5	Wera
SZS 0,4×2,5 SZF 0-0,4×2,5 *	Phoenix Contact
0.4×2.5×75 302	Wiha
AEF.2,5×75	Facom
210-719	Wago
SDI 0.4×2.5×75	Weidmuller

* OMRON's exclusive purchase model XW4Z-00B is available to order as SZF 0-0,4×2,5 (manufactured by Phoenix Contact).

Period and Terms of Warranty

Warranty Period

The product warranty is valid for a period of five years from the date of shipment from the factory.

Terms of Warranty

The warranty is valid only for the following operating conditions.

1. Average ambient operating temperature of the product: 40°C max. (See note.)

- 2. Average load rate of 80% max. (See note.)
- 3. Mounting method: Standard mounting

Note: The maximum ratings must be within the derating curve.

If the product fails for reasons attributable to OMRON within the above warranty period, OMRON will repair or replace the faulty part of the product at the place of purchase or the place where the product delivered without charge. This warranty does not cover the following types of failures.

- (1) Failures that result from handling or operation of the product under conditions or in environments that are not given in this document and not given in any other specifications exchanged between OMRON and the customer
- (2) Failures that originate in causes other than the delivered product itself
- (3) Failures caused by disassembly, modification, or repair of the product by anyone other than OMRON
- (4) Failures caused by applications or uses for which the product was not originally intended.
- (5) Failures caused by factors that could not be anticipated with the scientific or technical knowledge available when the product was shipped.
- (6) Failures caused by other causes for which OMRON is not responsible, such as natural disasters and other acts of God. This warranty is limited to the individual product that was delivered and does not cover any secondary, subsequent, or related damages.

МЕМО	

Terms and Conditions Agreement

Read and understand this catalog.

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranties.

(a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

(b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions.

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

OMRON Corporation Industrial Automation Company Kyoto, JAPAN

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V. Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC 2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200 Authorized Distributor:

© OMRON Corporation 2013-2017 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice. CSM_6_2_0318 Cat. No. T056-E1-04 1217 (0213)