## Max. 260 m<sup>3</sup>/h



## DC axial fans

\_

\_

\_

\_

Material:Housing: Die-cast aluminum<br/>Impeller: painted sheet steelDirection of air flow:Exhaust over strutsDirection of rotation:Counterclockwise,<br/>Iooking towards rotorConnection:Via single wires AWG 22,<br/>TR 64Highlights:Housing with grounding lug for<br/>screw M4 x 8 (Torx)

48 V design incl. screws. Weight: 650 g

se, - Go / NoGo alarm rotor - Alarm with speed limit

- External temperature sensor

- Possible special versions:

- Speed signal

- Internal temperature sensor

(See chapter DC fans - specials)

- PWM control input
- Analog control input
- Moisture protection
- Salt spray protection
- Degree of protection: IP 54

Series 5100 N			voltage	g	sure level	power level	e bearings s	consumption*	eed	e range	L <sub>10</sub> (40 °C) standard L <sub>10</sub> (T <sub>max</sub> ) standard	icy L <sub>10IPC</sub> age 17	
Nominal data	Air flow	Air flow	Nominal vo	Voltage range	Sound pressure	Sound powe	Sintec sleeve l Ball bearings	Power consi	Nominal speed	Temperature range	Service life L- ebm-papst str Service life L- ebm-papst st	Life expectancy L (40 °C) see page	Curve
Туре	m³/h	cfm	VDC	VDC	dB(A)	Bel(A)	∎/∎	Watts	<b>rpm</b> ⁻¹	°C	Hours	Hours	
5112 N	260	153	12	615	48	6.1		9.5	2 900	-25+72	80 000 / 37 500	135 000	1
5114 N	260	153	24	1230	48	6.1		9.5	2 900	-25+72	80 000 / 37 500	135 000	1
5118 N	260	153	48	2460	48	6.1		9.5	2 900	-25+72	80 000 / 37 500	135 000	1
3110 N	200	100	10	E 100	10	0.1		0.0	E 000	20	00 000 / 01 000		

\* Power consumption at free air flow. These values can be significantly higher in the operating point.



Air performance measured according to: ISO 5801. Installation category A, without contact protection. Noise: Total sound power level  $L_{W}A$  ISO 103002 measured on a hemisphere with a radius of 2 m. Sound pressure level  $L_{p}A$  measured at 1 m distance from fan axis. The values given are applicable only under the specified

The values given are applicable only under the specified measuring conditions and may differ depending on the installation conditions.

In the event of deviation from the standard configuration, the parameters must be checked after installation! For detailed information see

http://www.ebmpapst.com/general conditions



## ebmpapst

Finger guards from p. 242

2016-01

66