Technical Data Sheet

SCREW-ON MALE RECEPTACLE FULL DETENT





This document contains proprietary information and such information shall not be disclosed to any third party for any purpose whatsoever or used for manufacturing purposes without prior written agreement from Radiall. The data defined in this document are given as an indication, in the effort to improve our products; we reserve the right to make any changes judged necessary.



SCREW-ON MALE RECEPTACLE FULL DETENT



Radiall 🚺

This document contains proprietary information and such information shall not be disclosed to any third party for any purpose whatsoever or used for manufacturing purposes without prior written agreement from Radiall. The data defined in this document are given as an indication, in the effort to improve our products; we reserve the right to make any changes judged necessary.

Technical Data Sheet



SCREW-ON MALE RECEPTACLE FULL DETENT



- Connector must be screwed or unscrewed with adapted torque driver R282.339.001 (recommended coupling torque : 90 Ncm) screw driver : R282.360.001
- 2. Slide on the connector in F direction until it stops against the tool.



- 3. Screw the whole into the housing until activation of the torque driver.
- 4. Withdraw the tool and solder the center contact.

