

PYTHON Family Sensor Evaluation Kit Quick Start Guide



ON Semiconductor®

www.onsemi.com

This guide will help you get up and running using the PYTHON Family of CMOS Image Sensors with the ON Semiconductor G3 Evaluation Hardware and Sensor Studio II Software.

Before You Start

- **Evaluation Hardware and Supported Image Sensor**

Verify that you have the required hardware for the sensor being evaluated:

- ◆ G3 FPGA board
- ◆ Imager head board for the sensor being evaluated
- ◆ Optional lens mount kit

- **Sensor Studio II Software**

The most recent version can be downloaded at www.onsemi.com

- **USB**

USB 2.0 and USB 3.0 are supported.

- **Computer**

Windows 7 64 Bit. 2+ GHz processor, 8 GB RAM, USB 3.0/2.0 connection.

- **Power Supply**

12 V DC, 2 A, with 2.1 mm center positive DC power jack.

- **Cables**

2 meter USB 3.0 cable with Type A on the host end and micro 3.0 on the hardware end is included with the kit.

- **Lens**

A C/CS mount lens holder is provided with the kit. For larger optics, an F-mount is available in the optional Lens Mount Kit.

- **Table-top Tripod** (recommended)

Install Software

Install the software by running the appropriate “setup.exe” file, and check the boxes for installing the USB 3.0 drivers if they have never been installed.

Note that the 64-bit version of the USB3 driver currently is not digitally signed. For proper installation, press the F8 key during bootup to access Advanced Boot Options, and select Disable Driver Signature Enforcement.

Consult PleaseReadBeforeInstall.pdf, which comes with the SensorStudio installer, for more information.

EVAl BOARD USER’S MANUAL

Assemble Evaluation Hardware

- Install image sensor on image sensor headboard making sure that the image sensor is in the proper orientation.
- If using lens mount kit, assemble the appropriate configuration for the optic you intend to use (C or F). (see instructions provided in the kit)
- Plug the headboard into the G3 Capture Card and secure with card guide clips provided.
- If using the 1/4–20 mounting feature on the G3 Frame, ensure that your mounting screw does not contact the bottom side of the FPGA circuit board.
- **Plug in power and communications cables**
With the Evaluation Kit powered off, insert the USB cable into your PC. Insert the power plug into the receptacle on the Imager/FPGA board. Turn on the Power. Use Device Manager to verify “Truesense USB3” seen by the system.

Run Sensor Studio II

- **Shortcut**
To properly configure the shortcut icon, right click, choose properties and then select the compatibility tab. Set the OS for your OS and enable “run as admin”. The latter is needed if you install Sensor Studio II in the standard Program Files area which is owned by admin.
- **Launch Program**
Double click the Sensor Studio II desktop icon to launch the software.
- **Select Plugin**

Click the plugin button . Then choose the correct plugin in the list:

- ◆ Use PYTHON480 for PYTHON480 device
- ◆ Use PYTHON48 for PYTHON 300/500/1300/2000/5000 devices
- ◆ Use PYTHONxK for PYTHON 10K/12K/16K/25K devices
- ◆ An image display window and the control GUI will appear on the screen

• Connect to Hardware

- ◆ Select the “Connection” tab within the control GUI
- ◆ Click the Connect button
- ◆ The yellow indicator will change to green indicating that a connection has been established. The system is now ready to image. If there is a failure, the status box will turn red displaying an error message with more information.

Next Steps

Sensor Studio II provides a number of controls to evaluate operation of the sensor, including image capture, processing, and characterization.

Additional information on these controls is included in the Sensor Studio II help system, which is available from the HELP menu by selecting “SS2 and Python Help”.

For additional help in system setup, please contact ON Semiconductor at www.onsemi.com/imagesensors or by e-mail at is-support@onsemi.com.

ON Semiconductor and  are trademarks of Semiconductor Components Industries, LLC dba ON Semiconductor or its subsidiaries in the United States and/or other countries. ON Semiconductor owns the rights to a number of patents, trademarks, copyrights, trade secrets, and other intellectual property. A listing of ON Semiconductor's product/patent coverage may be accessed at www.onsemi.com/site/pdf/Patent-Marking.pdf. ON Semiconductor reserves the right to make changes without further notice to any products herein. ON Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does ON Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation special, consequential or incidental damages. Buyer is responsible for its products and applications using ON Semiconductor products, including compliance with all laws, regulations and safety requirements or standards, regardless of any support or applications information provided by ON Semiconductor. "Typical" parameters which may be provided in ON Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. ON Semiconductor does not convey any license under its patent rights nor the rights of others. ON Semiconductor products are not designed, intended, or authorized for use as a critical component in life support systems or any FDA Class 3 medical devices or medical devices with a same or similar classification in a foreign jurisdiction or any devices intended for implantation in the human body. Should Buyer purchase or use ON Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold ON Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that ON Semiconductor was negligent regarding the design or manufacture of the part. ON Semiconductor is an Equal Opportunity/Affirmative Action Employer. This literature is subject to all applicable copyright laws and is not for resale in any manner.

PUBLICATION ORDERING INFORMATION

LITERATURE FULFILLMENT:

Literature Distribution Center for ON Semiconductor
19521 E. 32nd Pkwy, Aurora, Colorado 80011 USA
Phone: 303-675-2175 or 800-344-3860 Toll Free USA/Canada
Fax: 303-675-2176 or 800-344-3867 Toll Free USA/Canada
Email: orderlit@onsemi.com

N. American Technical Support: 800-282-9855 Toll Free
USA/Canada
Europe, Middle East and Africa Technical Support:
Phone: 421 33 790 2910

ON Semiconductor Website: www.onsemi.com

Order Literature: <http://www.onsemi.com/orderlit>

For additional information, please contact your local Sales Representative