



TeraRanger Evo Mini Array Kits

Build low-cost multi-sensor applications in any configuration you need!

Tired of being constrained to pre-set sensor configurations? With our Evo Mini Array Kits build custom arrays, position sensors where needed, and forget about crosstalk! Developed for indoor distance measurement applications, the modular and low-cost kit comes in 2 configurations with either 4 or 8 sensors. Connect the sensors to the central Hub and stream out data via a single UART or USB interface, and benefit from 3 on-board modes, including crosstalk avoidance mode!

Key features

- Infrared Time-of-Flight technology
- Choose between kits with 4 or 8 sensors
- Optimized for indoor measurements 0.03 m to 3.3 m
- Each sensor has a wide 27° Field of View for maximum coverage
- All parts and accessories included in one easy-to-setup kit
- Multiple sensors single data output via USB or UART interface
- Built-in crosstalk avoidance system



Enabler for the following applications



Multi-point material level monitoring

Proximity sensing



Anti-collision for

mobile robots



Multi-sensor applications



Contactless inventory management

Copyright @ Terabee 2019 All Rights Reserved Terabee, 90 Rue Henri Fabre, 01630, St-Genis-Pouilly, France (5km from Geneva airport) +33 7 50 15 16 64 terarabee-sales@terabee.com www.terabee.com



Technical specifications

Product code	TR-AK-EVO-MINI-4 / TR-AK-EVO-MINI-8		
Performance			
Detection Principle	Infrared Time-of-Flight		
Light Source Wavelength	940 nm		
Use Environment	Indoors		
Repetability	< 5 mm		
Output Distance Resolution	1 mm		
Operating modes	Sequential mode		
	Simultaneous mode Tower mode		
Pango(1)			
Range ⁽¹⁾	0.03 m to 3.3 m per sensor ⁽²⁾ Up to +/- 2cm per sensor		
Accuracy ⁽¹⁾			
Update Rate ⁽¹⁾	4 sensor array	8 sensor array	
	Tower mode - 8 Hz	Tower mode - 8 Hz	
	Sequential mode - 4 Hz	Sequential mode - 2 Hz	
	Simultaneous mode - 16 Hz	Simultaneous mode - 16 Hz	
Field of View	27° per sensor (Max coverage 4 = 108 degrees		
	Max coverage 8 = 216 degrees)		
Electronics			
Supply Voltage V _{DC}	12V DC for the hub board		
Current Consumption	Power cable with open-end		
Current Consumption	50 mA per sensor (max. 8 sensors per hub board) 25 mA for the hub board		
Communication			
Interfaces	USB 2.0 Micro-B		
menaecs	UART, +3.3V level, 921600, 8, N, 1		
Visual Notification	WS2812B LED serial control output		
Mechanical data			
Dimensions	42 x 30 x 13 mm (incl. backboard) per sensor		
	55 x 55 x 10.7 mm for the hub board (incl. UART board)		
Weight	60 g for 4 sensor array kit & accessories		
	100 g for 8 sensor array kit & accessories		
Operating Temperature		-20°C to 75°C	
Sensor enclosure materials	ABS		
Mounting options	2 x M2 holes per sensor backboard 2 x M3 holes for the hub board		
	2 x M3 holes for the HUB board 2 x M3 holes for the UART board		
Type of Connection	USB 2.0 Micro-B		
3 F	UART, +3.3V level, 921600, 8, N, 1		
	WS2812B LED serial control output		
Conformity			
Reference Standard	CE, RoHS		

⁽¹⁾ Specifications are derived from tests in controlled conditions (target with 80% diffuse reflectivity, indoor fluorescent lighting, ambient temperature around 25°C). Note that bright sunlight, target surface reflectivity, and other variables can affect sensor performance

⁽²⁾ By default, the Teraranger Evo Mini sensor boots in 1-pixel long-range mode. When connected to Teraranger Hub Evo, these modes cannot be changed. To change pixel or range mode, TeraRanger Evo Mini needs to be connected to a compatible I2C/UART or USB 2.0 backboard interface and given a specific command. Please read the TeraRanger Evo Mini user manual for more information.



Operating modes

Simultaneous mode



All sensors connected to the Hub Evo are activated at the same time. Benefit from highest update rates.

Sequential mode



Sensors connected to the Hub Evo are activated one at a time (1 - 2 - 3 - etc). This mode is useful in configurations when crosstalk is likely and allows flexible sensor positioning.

Tower mode



Sensors are activated 4 at a time, first odd port numbers, then even port numbers on the Hub Evo. This mode is best used for 360° enviroment monitoring.

What's inside the box

	TR Evo Mini Array Kit 4	TR Evo Mini Array Kit 8
TR Evo Mini sensors	x 4 pcs	x 8 pcs
Hub backboards	x 4 pcs	x 8 pcs
FFC cables (20 cm)	x 4 pcs	x 8 pcs
TR Hub Evo	x 1 pcs	x 1 pcs
UART board	x 1 pcs	x 1 pcs
UART cable: DF13 6pin to open-end cable (22cm)	x 1 pcs	x 1 pcs
Micro-USB cable (50 cm)	x 1 pcs	x 1 pcs
Power cable with open ends (10cm)	x 1 pcs	x 1 pcs
Screws, spacers, nuts	x 6 pcs	x 6 pcs

+33 7 50 15 16 64 terabee-sales@terabee.com www.terabee.com



Dimensions

TeraRanger Hub Evo





+33 7 50 15 16 64 terabee-sales@terabee.com www.terabee.com