


#### **ASSEMBLY INSTRUCTIONS:**

- 1. PREPARE CABLE ENDS, CONNECT TO CONNECTOR
- 2. INSERT CABLE INTO ONE HALF OF HOOD
- 3. INSERT THE JACKSCREWS IN THE SADDLE WASHERS. PLACE THE JACKSCREWS INTO THE HOOD WITH THE CABLE
- 4. PLACE THE OTHER HALVE OF THE HOOD ON TOP OF THE FIRST HALF, MAKING SURE NO WIRES ARE PINCHED
- 5. HOLDING THE HOOD HALVES TOGETHER, INSERT THE MOUNTING SCREWS THROUGH THE HOODS IN OPPOSITE DIRECTIONS. TIGHTEN THE TWO HALVES TOGETHER
- 6. INSERT STRAIN RELIEF ROD INTO THREADED HOLE.
  TIGHTEN SNUG BUT NOT TIGHT ENOUGH TO CUT THE WIRE
  OR JACKET



ITEM No. 2



ROD



SADDLE WASHER

## RoHS COMPLIANT

#### **PLASTIC**

0



THESE DRAWINGS AND SPECIFICATIONS ARE THE PROPERTY OF NOrComp AND SHALL NOT BE REPRODUCED, COPIED OR USED AS THE BASIS FOR THE MANUFACTURE OF SALE OF APPARATUS WITHOUT WRITTEN PERMISSION.

SCALE:
N.T.S.

DRAWN:

C. SMITH

CHECKED:

03-30-06


DATE: X

SHEET OF REV

DATE:


NorComp

BACKSHELL - 978 SERIES



#### **ASSEMBLY INSTRUCTIONS:**

- 1. PREPARE CABLE ENDS, CONNECT TO CONNECTOR
- 2. IF CABLE IS SHIELDED, WRAP SHIELD AND/OR GROUND WIRE BACK OVER CABLE JACKET. CUT OFF ANY EXCESS WIRE. INSERT INTO ONE HALF OF HOOD
- 3. INSERT THE JACKSCREWS IN THE SADDLE WASHERS. PLACE THE JACKSCREWS INTO THE HOOD WITH THE CABLE
- 4. PLACE THE OTHER HALVE OF THE HOOD ON TOP OF THE FIRST HALF, MAKING SURE NO WIRES ARE PINCHED
- 5. HOLDING THE HOOD HALVES TOGETHER, INSERT THE MOUNTING SCREWS THROUGH THE HOODS IN OPPOSITE DIRECTIONS. TIGHTEN THE TWO HALVES TOGETHER
- 6. INSERT STRAIN RELIEF ROD INTO THREADED HOLE. TIGHTEN SNUG BUT NOT TIGHT ENOUGH TO CUT THE WIRE **OR JACKET**



ITEM No. 2





SADDLE **WASHER** 

# ROHS COMPLIANT

### **METALIZED PLASTIC**



THESE DRAWINGS AND SPECIFICATIONS ARE THE PROPERTY OF NorComp AND SHALL NOT BE REPRODUCED, COPIED OR USED AS THE BASIS FOR THE MANUFACTURE OF SALE OF APPARATUS

WITHOUT WRITTEN PERMISSION.

NorComp

DRAWN: C. SMITH		DATE:	03-30-06	
CHECKED:		DATE:	Х	
SCALE:	SHFFT	ΩF		RFV

N.T.S. 0

DWG NO.

**BACKSHELL - 978 SERIES**